

PS904




Power Supply Installation Instructions

A DANGER A

To avoid risk of electric shock, turn off AC power before installing or servicing PS904 power supply

These instructions cover the following parts:



PS904 Power Supply Specifications:

Innut	120/240 \/AC 1.7	A FO/COLLY High Voltage Close 1 Wiring Dequired
Input	120/240 VAC, 1.7 A, 50/60Hz, High Voltage Class 1 Wiring Required	
Output	4 Amp DC @ 12/24 VDC	
Enclosure	14" H x 12" W x 4" D (8 knockouts, 1/2" or 3/4")	
Temperature Range	32°-120° F (0°- 49° C)	
Fuse	F1, T4A	A CAUTION A
	250 VAC	For protection against risk of fire, replace fuse with same type and rating
Compliance	UL 294, ULC-S318, RoHS, & FCC Part 15, Class 2 Output	
Compatible Boards	900-2RS	INST. INSTRUCTIONS - 24125007
(Optional, 2 boards maximum)	900-4R	INST. INSTRUCTIONS - 44487106
	900-4RL	INST. INSTRUCTIONS - 44487080
	900-8F	INST. INSTRUCTIONS - 44487106
	900-8P	INST. INSTRUCTIONS - 44487106
Fire Alarm Input Board (Optional)	900-FA (Requires one option board above) INST. INSTRUCTIONS - 44487072	
Battery Backup Board (Optional)	900-BB	INST. INSTRUCTIONS - 44487064

Mounting Notes

The PS904 must be installed in accordance with the article 760 of the National Electrical Code or NFPA 72, Canadian Electrical Code, or any other applicable codes.


Install the PS904 indoors within the protected premises.

Check national and local codes for additional installation requirements.


Enclosure must be firmly mounted to a solid surface using hardware suitable for the surface.

1 Mount Power Supply


1a Mark 2 Top Holes





1b Secure Enclosure with 4 Screws



2 Secure enclosure door










Refer to 900-BB Instructions




Verify AC LED is On = GREEN

Verify DC LED is On = RED

Verify BB LED (if applicable) is On = AMBER

Option Boards

Refer to appropriate instructions if any board shown below is factory-installed



Note: When installation is complete, secure enclosure door with screws (provided) or keylock.





PS-900 Series Option Boards




Installation Instructions

A DANGER A


To avoid risk of electric shock, turn off AC power to power supply before installing or wiring option board


This sheet covers:



Refer to installation instructions for compatible supply models - PS902, PS904, PS906, and PS914.

1 INSTALL OPTION BOARD(S) INTO POWER SUPPLY





Customer Service

1-877-671-7011

www.allegion.com

900-4R


900-4R Specifications

Inputs I1-I4	Dry contacts required (Closed = Active)	
	Connect control contacts between SC (Signal Common) and any input	
Outputs 01-04	• Form C contacts rated 30VDC, 3A (dry) • 12/24VDC, 3A (wet) when AC powered • 9.6-13.2VDC or 19.2-26.4VDC when battery powered • Maximum load cannot exceed power supply ratings or 6A for outputs combined	
Board Input Power	Board requires 0.18A max. of power supply output current to operate	
Temperature Range	32°-120° F (0°- 49° C)	
Compliance	UL 294, ULC-S318, RoHS, & FCC Part 15	
Fire Alarm Input	Accepts 900-FA Fire Alarm Board (Optional)	

Function: Four independent dry-contact inputs control four Form C outputs

Powered Outputs

(Default)



Dry Contact Outputs (Optional)

For dry contact outputs, remove appropriate jumpers and rotate 90°, then reinstall (Zone 1 - Zone 4)

